



- NOTES:
1. CONCRETE SURFACES AT ATTACHMENTS TO BE SMOOTH BEFORE INSTALLATION
  2. WHEN USING GEO-TEXTILE, DO NOT TERMINATE BENEATH BAR OR NEOPRENE GASKET.

<p><b>Firestone</b></p> <p>20 <i>Trailing for Title</i> 09</p>	<p><b>PondGard Membrane</b></p> <p>Horizontal Mechanical Attachment</p> <p>Below the Water Line</p>	<p><b>Detail No. PGT-3</b></p> <p><b>Systems PondGard</b></p>
----------------------------------------------------------------	-----------------------------------------------------------------------------------------------------	---------------------------------------------------------------